

Our ready to go vinyl letters and graphics, you can adhere our vinyl to almost any non-porous surface.

STEP 1 - Surface Preparation

Use a tape measure or a ruler to determine the exact area where the sign will be placed. We recommend drawing a horizontal guide line and a vertical line in the center. Make sure the surface is clean. If needed, clean the surface with a clean, dry cloth.

STEP 2 - Prepare Do-It-Yourself Installation Signage

We will provide you with vinyl that has transfer tape (looks and feels like white masking tape) on one side and backing paper (white and shiny) on the other. Carefully peel the backing paper away from the letters or graphic which should remain on the transfer tape.

STEP 3 - Vinyl Application

Place the taped vinyl on the pre-measured surface, using the lines to position the vinyl correctly onto the surface. Press any air bubbles out from underneath the sign. Start in the middle and press towards the edges of the letters or the graphic. Once the air bubbles are gone, firmly press the vinyl onto the surface.

STEP 4 - Transfer Tape Removal

Carefully peel back the transfer tape. This will leave the vinyl letters or the graphic on your surface.

Applications for Do-It-Yourself Installation include:

Window Graphics

Vehicle Lettering

Custom Graphics and Logos

STEP 1 - Clean the Surface

Using a strong cleaner which will not harm the sign surface, wipe the entire area and beyond. Wipe the area again with a very mild detergent or just plain water to remove any residue. Wipe the surface dry with a lint-free cloth.

STEP 2 - Align the Vinyl Lettering

Place masking tape along the top edge of the sheet. With the backing paper and application tape still attached, position the vinyl lettering so that it is properly aligned and level.

STEP 3 - Tape the Graphics in Place

Using the squeegee, stick the masking tape to the sign surface to hold it in place. Use care to make sure the sheet with letters is not wrinkled.

STEP 4 - Cut Long Sheets to Size (optional)

Lettering which is too long to handle easily can be cut vertically with scissors between letters or words. Cut through the Application Tape and Backing Paper, leaving each piece of the sheet attached to the surface with the masking tape.

STEP 5 - Remove Backing Paper

Flip the sheet up using care not to peel the masking tape away. Remove the wax coated backing paper by slowly peeling it away. Be sure the the vinyl letters remain on the application tape.

STEP 6 - Apply Vinyl Letters

Starting at the top edge, firmly slide the squeegee side to side to seal the letters to the surface. Slowly work your way to the bottom of the sign. Do not let the letters touch the sign surface until the squeegee passes over the area.

STEP 7 - Remove Application Tape

Slowly peel away application tape, making sure that all letters are sticking properly. Use your squeegee if any areas of the letters are not sticking well. Air bubbles can be removed by cutting a small slice in the letter and working air out with the squeegee.